



SAFETY CRAFT KNIFE

A SAFETY CRAFT KNIFE IS A VERY SHARP CUTTING TOOL. IT IS USED WHEN CUTTING AND TRIMMING CARD, LEATHER, VINYL, CARPET AND MANY OTHER MATERIALS. IT HAS A CRAFT KNIFE BLADE WHICH MUST BE HANDLED CAREFULLY. THE SAFETY CRAFT KNIFE USUALLY HAS A RETRACTABLE BLADE, WHICH IS LOCKED IN THE 'CUTTING POSITION' WHEN IN USE AND RETRACTED WITHIN THE CASING, WHEN BEING STORED. IT IS COMMON PRACTICE TO USE A STEEL SAFETY RULER WHEN CUTTING STRAIGHT LINES. THIS HELPS GUIDE THE CUTTING BLADE AND ACTS AS A REMINDER TO KEEP THE SECOND HAND AWAY FROM THE MOVING BLADE.

HELPFUL LINK



SAFETY RULER



HELPFUL LINK: <https://technologystudent.com/health1/safeagain2.html>


BLADE LOCKED IN CUTTING POSITION




INTERNAL VIEW OF CASE




BLADE WITHDRAWN IN SAFETY POSITION



INTERNAL VIEW OF CASE



SAFETY CRAFT KNIFE



INTERNAL VIEW OF CASE

