



THE FRAME SAW

A FRAME SAW IS THE TRADITIONAL SAW FOR RIPPING AND CROSSCUTTING LENGTHS OF WOOD. THE BLADE IS HELD IN TENSION BY THE TENSIONING BAR. WHEN THE BLADE NEEDS TO BE TENSIONED, THE TENSIONING SCREWS AT EITHER END ARE TURNED UNTIL THE BLADE IS TENSIONED SUFFICIENTLY. THE FRAME SAW IS IDEAL FOR CROSSCUTTING AND RIPSAWING, ESPECIALLY IN THE ABSENCE OF A CIRCULAR SAW OR BAND SAW.



CROSS CUTTING WITH THE FRAME SAW

(SIDE VIEW)



RIPSAWING WITH THE FRAME SAW

(PLAN VIEW)

